



Spare parts list Remote Control HF cpl



Spare parts list Remote Control HF cpl



Spare parts list Remote Control HF cpl

| Pos. | Qty | Part number | Description |
|--------------|-----|-------------|-------------------------------------|
| HF-remote-1 | 1 | 64190400-1 | Housing remote control, lower |
| HF-remote-2 | 1 | 64190400-2 | Housing remote control, upper |
| HF-remote-3 | 1 | 98800100 | Symbol plate HF-remote |
| HF-remote-4 | 2 | 55910100 | Bracket for strap/belt on remote |
| HF-remote-5 | 1 | 24200100 | Seal for Remote control box |
| HF-remote-6 | 1 | 64410100 | Joystick remote control |
| HF-remote-7 | 1 | 64410200 | Knob for joystick on remote control |
| HF-remote-8 | 1 | 64410300 | Rubber boot for joystick |
| HF-remote-9 | 1 | 64031301 | Circuit board on joystick HF-remote |
| HF-remote-10 | 2 | 64410900 | Top cover knob on pot. HF-remote |
| HF-remote-11 | 2 | 64410700 | Knob for potentiometer on remote |
| HF-remote-12 | 2 | 64410800 | Pointer for knob on pot. Remote |
| HF-remote-13 | 2 | 24200200 | Sealnut for pot on remote |
| HF-remote-14 | 1 | 64031201 | Potentiometer unit HF-remote |
| HF-remote-15 | 2 | 64410400 | Switch HF-remote |
| HF-remote-16 | 2 | 24200300 | Rubber seal for switch on HF-remote |
| HF-remote-17 | 1 | 64410600 | Knob for switch HF-remote, blue |
| HF-remote-18 | 1 | 64410500 | Knob for switch HF-remote, red |
| HF-remote-19 | 1 | 64061100 | LED green for remote with joystick |
| HF-remote-20 | 1 | 64230700 | Emergency stop button HF-remote |
| HF-remote-21 | 1 | 16242600 | Washer for killswitch HF-remote |
| HF-remote-22 | 1 | 64230800 | Contact block killswitch HF-remote |
| Not shown | 1 | 64880501 | Cable for HF-remote cpl |
| Not shown | 1 | 89090100 | Waist-strap for remote control |
| Not shown | 1 | 89090200 | Shoulder-strap for remote control |